

Sunways Portal APP Basic Introduction



CONTENTS

01 Overview

02 I am an Owner




03 I am a Distributor

04 Others

/01

Overview

Overview



Sunways Portal APP is a mobile application used to manage PV plants. The app allows you to create PV plants, manage devices, view energy data, set parameters and perform routine maintenance. It is a convenient platform for maintenance

Downloading and Installing the App

Method 1: Access <https://www.sunways-portal.com/download/download.html> using the mobile phone browser and download the latest installation package

Method 2: Search for Sunways Portal in Google play & Apple Store to download and install the app

Method 3: Scan the QR code to download and install the app.

Note: Mobile phone operating system: Android 8, IOS 9 or above




/02

I am an Owner

Registration

If you do not have
an account, go to
register



English ▾

sunways


Energy • Connects All



☐ Remember me

[Forgot password?](#)

Demo Site
Version: 1.3.2



< Owner Registration





☐ I have read and agree to [Terms of Use](#) and [Privacy Policy](#)

Note 

Only owner/end-user
account can be
registered via APP. For
distributor account,
please contact your
superior distributor or
Sunways

Log in

If you already have
an account, Log in

English ▾

sunways
Energy • Connects All

☒ Remember me

Log In

[Forgot password?](#) [Register](#)

Demo Site
Version: 1.3.2

Plants		
Plants/SN		
	测试电站-000 E-today Current Power	-- kWh -- kW
	测试电站-001 E-today Current Power	-- kWh -- kW
	测试电站-003 E-today Current Power	-- kWh -- kW
	test plant E-today Current Power	117.7 kWh 46.877 kW



Plants Notification Me

Log Out

Step 1: Log in to the overview screen, tap[Me]

Step 2: In [Me] screen, tap[Settings]

Step 3: Tap [Log out]




Create a Plant

Step 1: Log in to the overview screen, tap[Me]

Step 2: In [Me] screen, tap [Plant management] , enter the page and click 「+」 in the upper-right corner

Step 3: Enter the PV plant information as required, including [Device Scanning]-[Installation Info]-[Other Info] After completed, tap[Complete], end.




Add Device

Precondition: You already have created PV plant. If not, please refer to the previous page(Create a Plant).

Step 1: Log in to the overview screen, tap[Me]

Step 2: In [Me] screen, tap [Plant management] , enter the page and click 「+」 in the upper-right corner

Step 3: Enter the device information as required, tap[Select plant] down the page, choose the right related plant, complete.




WIFI Configuration

Step 1: Log in to the overview screen, tap[Me]

Step 2: In [Me] screen, tap [WIFI Configuration.] , enter the page and click 「To Connect」, connect the hotspot of inverter, go back to the APP and tap [To configure]

Step3: page will automatically go to 10.10.100.254, both username and password are admin. After login, the setting page will show. Refer to the WIFI Module User Manual for more guidance.



[WIFI Module User Manual](#)

Settings

Step 1: Log in to the overview screen, tap[Me]

Step 2: In [Me] screen, tap[Settings]

Step 3: Account security: change your email address and login password

Electricity price setting: set the electricity unit price and currency


Date and time: change the date format

Default language: change the displayed language

Help: frequently asked questions




After-sale service: contact method of after-sale service worldwide

About: the software version of the APP, terms of use, privacy policy, official website and check for updates.






View Plant

Log in to [Plants] screen, filter the PV plants to be displayed, tap [Plant Name] to view the plant details.



View Device

Log in to overview screen, tap [Plants], tap [Devices], you can see real-time information, historical information and basic information of device



/03

I am a Distributor

English ▾

sunways

Energy • Connects All

13102@qq.com

.....

☒ Remember me

Log In

[Forgot password?](#) [Register](#)

Demo Site
Version: 1.3.2



Note



Only owner/end-user account can be registered via APP. If you don't have an account yet, please contact your superior distributor or Sunways

Log Out

Step 1: Log in to the overview screen, tap[Me]

Step 2: In [Me] screen, tap[Settings]

Step 3: Tap [Log out]




Create a Plant

Step 1: Log in to the overview screen, tap[Me]

Step 2: In [Me] screen, tap [Plant management] , enter the page and click 「+」 in the upper-right corner

Step 3: Enter the PV plant information as required, including [Device Scanning]-[Installation Info]-[Other Info] After completed, tap[Complete], end.




Add Device

Precondition: You already have created PV plant. If not, please refer to the previous page(Create a Plant).

Step 1: Log in to the overview screen, tap[Me]

Step 2: In [Me] screen, tap [Plant Mgt.] , enter the page and click 「+」 in the upper-right corner

Step 3: Enter the device information as required, tap[Select plant] down the page, choose the right related plant, complete.







WIFI Configuration

Step 1: Log in to the overview screen, tap[Me]

Step 2: In [Me] screen, tap [WIFI Configuration.] , enter the page and click 「To Connect」, connect the hotspot of inverter, go back to the APP and tap [To configure]

Step3: page will automatically go to 10.10.100.254, both username and password are admin. After logging in, the setting page display. Refer to the WIFI Module User Manual for more guidance.



[WIFI Module User Manual](#)

Settings

Step 1: Log in to the overview screen, tap[Me]

Step 2: In [Me] screen, tap[Settings]

Step 3: Account security: change your email address and login password

Electricity price setting: set the electricity unit price and currency


Date and time: change the date format

Default language: change the displayed language

Help: frequently asked questions


After-sale service: contact method for after-sale service worldwide

About: the software version of the APP, terms of use, privacy policy, official website and check for updates.






View Account Data

Log in to the [Overview] screen, this page displays the status of the plants, power yield conditions, revenue, energy-saving, and emission reduction.






View Plants

Log in to [Plants] screen, filter the PV plants to be displayed, tap [Plant Name] to view the plant details.



View Device

Log in to overview screen, tap [Plants], tap [Devices], you can see real-time information, historical information and basic information of device.








Parameter Settings

For distributor account, device parameters can be set through app.

Step 1: Log in to overview screen, tap [Me]

Step 2: In the [Plant management], tap the device that you want to set

Step 3: Tap[...] in the upper-right corner, tap[Parameter Setting]





/04

Others

Notification




Sunways will send notifications when the system is updating or maintenance is scheduled.



Forget password

Step 1: In login screen, tap [Forgot password] and enter the email address.

Step 2: Verify email first, then reset the password, and log in with the new password



98.00%

Efficiency

49.50kwh

Daily Generation

94.7t

Reducing CO₂ Emissions

5.4MWh

Monthly Generation

21.11kw
Real-time Power

110kwp
Capacity

THANK YOU

94.98MWh

94.98MWh

2212.55Trees

Equivalent Tree Planting

Real-time Power 2020-11-09



Generation 2020-11

